

Triton Analytics Corporation
 16840 Barker Springs, #302
 Houston, TX 77084
Z-type Summary

sample: **No. 2 Diesel**

data file/run date 103515 7/18/02

TAC ref: xxxx

Assumed HTSD recovery: **100 % boiling below 1000F**

Note: values reported represent only a "best estimate"

Weight Percentage

Iso/normal paraffin ratio
 weighted average 0.90
 average carbon # of n-paraffins 15.3

Z number Summary

+2	38.64	Paraffins:	38.64
+0	22.27		
-2	13.50		
-4	3.72	Cyclanes:	39.49
-6p	0.00	Phenols	
-6	4.03		
-8	3.58		
-10b	0.42	Benzothiophenes	
-10	1.57	Monoaros:	9.60
-12	6.02		
-14	4.55		
-15	0.00	Carbazoles	
-16db	0.37	Dibenzothiophenes	
-16	0.73	Diaros:	11.67
-18	0.59		
-20	0.02		
-22bn	0.00	Benzenaphthothiophenes	
-22	0.01	Triaros:	0.61
-24	0.00		
-26	0.00		
-28	0.00	Tetraaros:	0.00
-30	0.00		
-32	0.00	Pentaaros:	0.00

100.00

average # of carbons 14.8
 average # of hydrogens 27.7
 average # of oxygens 0.00
 average # of sulfurs 0.01
 average # of nitrogens 0.00
 average molecular weight 206.0

phenolic oxygen 0.00 wt %
 thiophenic sulfur 0.13 wt %
 carbazolic nitrogen 0.00 wt %

Triton Analytics Corporation
 16840 Barker Springs, #302
 Houston, TX 77084
Z-Type vs. Carbon Number

sample: **No. 2 Diesel**


data file/run date: 103515 7/18/02
 TAC ref: xxxx
 Assumed HTSD recovery: 100 % boiling below 1000F

Note: values reported represent only a "best estimate"

Z number C#	+2(i)	+2(n)	0	-2	-4	-6	-6	-8	-10	-10	-12	-14	-15	-16	-16	-18	-20	-22	-22	-24	-26	-28	-30	-32
						phenols		benzo-	thiophenes					dibenzo-			benzo-	aphtho-						
								thiophenes						thiophenes			thiophenes							
5	0.00	0.00	0.00																					
6	0.01	0.00	0.01			0.00	0.00																	
7	0.02	0.00	0.16	0.00		0.00	0.02																	
8	0.08	0.09	0.39	0.01		0.00	0.10	0.00	0.00															
9	0.21	0.25	0.71	0.11		0.00	0.23	0.01	0.02	0.01														
10	0.46	0.62	1.20	0.45	0.00	0.00	0.28	0.08	0.08	0.02	0.10													
11	1.04	1.43	2.10	1.33	0.05	0.00	0.34	0.30	0.09	0.06	0.84													
12	1.31	1.83	2.20	1.79	0.17	0.00	0.36	0.56	0.07	0.08	1.93	0.21	0.00	0.08	0.01									
13	1.82	2.02	2.53	2.05	0.34	0.00	0.42	0.67	0.06	0.15	1.57	0.83	0.00	0.14	0.08									
14	1.90	2.05	2.35	1.77	0.52	0.00	0.45	0.55	0.04	0.25	0.81	1.23	0.00	0.11	0.19	0.15								
15	1.91	2.18	2.26	1.55	0.59	0.00	0.46	0.41	0.03	0.33	0.38	1.11	0.00	0.04	0.23	0.23								
16	1.90	2.02	2.00	1.20	0.57		0.41	0.31	0.01	0.26	0.19	0.62	0.00	0.00	0.13	0.12	0.00	0.00	0.01					
17	1.70	2.31	1.85	1.00	0.47		0.32	0.26	0.00	0.18	0.11	0.33	0.00	0.00	0.06	0.02	0.01	0.00	0.00					
18	1.80	2.07	1.58	0.81	0.39		0.25	0.19	0.00	0.11	0.05	0.11	0.00	0.00	0.02	0.00	0.01	0.00	0.00	0.00				
19	1.85	1.70	1.28	0.63	0.28		0.17	0.12	0.00	0.06	0.03	0.07	0.00	0.00	0.01	0.00	0.00	0.00	0.00	0.00				
20	1.27	1.03	0.86	0.40	0.17		0.11	0.07	0.00	0.03	0.01	0.02	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
21	0.61	0.51	0.49	0.23	0.09		0.05	0.04	0.00	0.02	0.01	0.02		0.00	0.00	0.01	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
22	0.26	0.15	0.21	0.11	0.05		0.03	0.01	0.00	0.01	0.00	0.00		0.00	0.00	0.02	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
23	0.12	0.03	0.07	0.04	0.02		0.01	0.01		0.00	0.00	0.00		0.00	0.00	0.02	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
24	0.04	0.00	0.02	0.01	0.01		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.02	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
25	0.01	0.00	0.01	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
26	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
27	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
28	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
29	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
30	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
31	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
32	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
33	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
34	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
35	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
36	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
37	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
38	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
39	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
40	0.00	0.00	0.00	0.00	0.00		0.00	0.00		0.00	0.00	0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
sum	18.34	20.30	22.27	13.50	3.72	0.00	4.03	3.58	0.42	1.57	6.02	4.55	0.00	0.37	0.73	0.59	0.02	0.00	0.01	0.00	0.00	0.00	0.00	0.00

Triton Analytics Corporation
16840 Barker Springs, #302
Houston, TX 77084
Normal Paraffin Distribution


No. 2 Diesel



Triton Analytics Corporation
 16840 Barker Springs, #302
 Houston, TX 77084

sample name: **No. 2 Diesel**
 run date: 7/18/02

data file: **103515**
 TAC ref: xxxx




I0	Indene	F0	Fluorene	Fl/Py	Fluoranthene/pyrene
N0	naphthalene	F1	C1-fluorenes	FP1	C1-fluoranthene/pyrenes
N1	C1-naphthalenes	F2	C2-fluorenes	FP2	C2-fluoranthene/pyrenes
N2	C2-naphthalenes	F3	C3-fluorenes	FP3	C3-fluoranthene/pyrenes
N3	C3-naphthalenes	F4	C4-fluorenes	FP4	C4-fluoranthene/pyrenes
N4	C4-naphthalenes	F5	C5-fluorenes	FP5	C5-fluoranthene/pyrenes
N5	C5-naphthalenes	F6	C6-fluorenes	FP6	C6-fluoranthene/pyrenes
N6	C6-naphthalenes	An	Anthracene/phenanthrene	Ba/C0	Benzo(a)anthracene/chrysene
N7	C7-naphthalenes	P1	C1-anthracene/phenanthrenes	C1	C1-Benzo(a)anthracene/chrysenes
N8	C8-naphthalenes	P2	C2-anthracene/phenanthrenes	C2	C2-Benzo(a)anthracene/chrysenes
AcI	Acenaphthylene	P3	C3-anthracene/phenanthrenes	C3	C3-Benzo(a)anthracene/chrysenes
Ace	Acenaphthene	P4	C4-anthracene/phenanthrenes	C4	C4-Benzo(a)anthracene/chrysenes
		P5	C5-anthracene/phenanthrenes	C5	C5-Benzo(a)anthracene/chrysenes
		P6	C6-anthracene/phenanthrenes	C6	C6-Benzo(a)anthracene/chrysenes
		P7	C7-anthracene/phenanthrenes	Bf	Benzo(b),(k)fluoranthenes/(a)pyrene
		P8	C8-anthracene/phenanthrenes	Da	Dibenz(a,h)anthracene
				Id	Indeno(1,2,3-cd)pyrene/benzo(ghi)perylene

Triton Analytics Corporation
 16840 Barker Springs, #302
 Houston, TX 77084

sample name: **No. 2 Diesel**
 run date: 7/18/02

Excel file: **103515**
 TAC ref: xxxx



B0	Benzothiophene	D0	Dibenzothiophene	BN0	Benzonaphthothiophene
B1	C1-benzothiophenes	D1	C1-dibenzothiophenes	BN1	C1-Benzonaphthothiophenes
B2	C2-benzothiophenes	D2	C2-dibenzothiophenes	BN2	C2-Benzonaphthothiophenes
B3	C3-benzothiophenes	D3	C3-dibenzothiophenes	BN3	C3-Benzonaphthothiophenes
B4	C4-benzothiophenes	D4	C4-dibenzothiophenes	BN4	C4-Benzonaphthothiophenes
B5	C5-benzothiophenes	D5	C5-dibenzothiophenes	BN5	C5-Benzonaphthothiophenes
B6	C6-benzothiophenes	D6	C6-dibenzothiophenes	BN6	C6-Benzonaphthothiophenes
B7	C7-benzothiophenes	D7	C7-dibenzothiophenes	BN7	C7-Benzonaphthothiophenes
B8	C8-benzothiophenes	D8	C8-dibenzothiophenes	BN8	C8-Benzonaphthothiophenes

average molecular weights
 188.5 Benzothiophenes

202.7 Dibenzothiophenes

234.0 Benzonaphthothiophenes

weight percent thiophenic sulfur 0.13 %